


Note bolt thread area should be on outside of hoist
 If this print has colored cables they are for easier understanding of how they are strung
 Cables from the factory are colored too. They won't all match to these colors.



Typical leg bolt up 4-screws

SEE PARTS LIST FOR ABOVE PART NUMBERS
 DOCUMENT# V45PARTSLIST
 READ MANUAL BEFORE USING HOIST.
 Manual, parts list and drawing on the web WWW.CRAFTLANDER.COM

Please Note that cable lifting method before 1997 was different than above. Please contact dealer for correct cables and parts.

2	10/9/02	New style column guides	SB
1	3/25/97	Cable lift method changed	RW
Rev	Date	Description	Int
<p><i>NACRAFT</i></p> <p>Metal Products</p> <p>402 Southline Rd. Roscommon, MI 48653</p>			
Scale:	None	Approved by:	Drawn by: RLW
Date:	1/30/05		Revised by: SB
Assembly & Part locations for V45J08, V45I14 and V45I20			



Drawing Number
 A-107-R